

MONOGRAM FLOORS

INSTALLATION INSTRUCTIONS
ENGINEERED HARDWOOD

Table of Contents

3 - Pre Installation

6 - Subfloor

10 - Radiant Heat

14 - Below Grade Installation

16 - Glue Down Installation

18 - Glue Down w/ Nail Assist Installation

19 - Floating Installation

Attention

Before starting installation, read all instructions thoroughly. All installation instructions must be followed for warranties to be considered valid. Pre-inspect the job site prior to delivery of the floor to ensure the structure is suitable for hardwood flooring installation using the following guidelines:

Owner/Installer Responsibility

1. Inspect the hardwood flooring in a well-lit condition to ensure proper identification of any potential problems. If the flooring is not acceptable, contact your retailer and/or distributor to arrange shipment of replacement material. Defective product will be replaced. Material that is subjectively viewed as unacceptable but falls within Monogram Floors' grading norms will not be replaced.

IF THE FLOORING AS SUPPLIED WILL NOT SATISFY THE CUSTOMER IN FULL, DO NOT PROCEED TO INSTALL. The decision not to proceed must be made within the first 10% or 100 square feet of flooring boxes opened, whichever is less. Open boxes exceeding this amount will not be eligible for return.

2. Prior to installation of any flooring, the installer must ensure the job site and sub-floor conditions meet the requirements specified in these instructions.

3. Hardwood flooring installation should be one of the last items completed on the construction project. Limit foot traffic on the finished wood floor.

Grading Standards

General Rules:

Flooring shall be tongue and grooved and end matched (unless otherwise indicated). Flooring shall not be considered of standard grade unless properly dried. The drying standard for Monogram products shall be 8 to 10% moisture content by volume with a plus or minus factor of 2% for storage conditions in various climate zones.

Grading Rules:

Monogram Floors uses a proprietary grade for manufacturing our floors. Proprietary grades are generally referred to as Mill Run. Instead of separating the lumber into traditional NOFMA/NWFA grades, the flooring is a mix of grades. This enables us to produce wider and longer boards. Monogram's grading rules allow for filled knots, mineral streaks, open checks, tight checks, and filled checks. Bird peck, pin worm hole, and flag worm hole are acceptable (any insects are killed in drying process). Plank faces may also contain unlimited amounts of heart wood (dark portion of log) and/or sap wood (light portion of log).

Environmental Issues

Damage caused by inappropriate handling, environment, installation, or maintenance issues will not be considered in relationship to grade. NOTE: DO NOT OPEN BOXES PRIOR TO INSTALLATION.

Storage and Handling

Handle and unload wood flooring with care. Store in a dry place; Make sure to provide at least a four-inch space (using dry 4" x 4" stickers or a dry pallet that provides enough clearance under boxes for proper air movement. Prior to delivery of flooring, outside doors and windows must be in place.

All concrete, masonry, plastering, and other "wet" work must be complete and thoroughly dry prior to flooring installation. The roofing and the exterior shell of the structure must be finished and weather tight with doors and windows installed.

The wall coverings should be in place and all painting completed—except for the final coat on the base molding. Room temperature and humidity should be consistent with year-round conditions for at least one week prior to installation. When possible, install base molding after floor installation is complete.

HVAC MUST BE RUNNING WITH A ROOM TEMPERATURE OF BETWEEN 60°F TO 80°F AND RELATIVE HUMIDITY OF BETWEEN 30 AND 55%. NOTE: HICKORIES TO BE MAINTAINED AT 35-55%.

Acclimation & Climate Control

Wood flooring is a hygroscopic material subject to dimensional change as a result of variations in moisture, temperature, and humidity within the surrounding environment. Wood flooring simply needs to reach a moisture content level in equilibrium with the surrounding environment (EMC) IN WHICH IT WILL BE INSTALLED, AT OR NEAR NORMAL LIVING CONDITIONS (Defined as between 30 -55% RH 60 to 80° F - Hickories to be maintained at 35-55%). The process of reaching this equilibrium is defined as acclimation, which allows the wood to properly adjust itself to the normal living conditions within the structure; that is, the temperature, humidity conditions, and moisture content that will typically be experienced once the structure is occupied and stable indoor climate control is exercised. NOTE: Intended for indoor use only. NORMAL ENVIRONMENTAL CONDITIONS MUST BE MET TO ENSURE OPTIMAL PERFORMANCE.

Wood Reactions to Environmental Change

Low RH

Wood shrinks and splits. Joints become loose and the elements no longer fit together tightly. Veneers and inlays suffer- If the underlying carcass wood shrinks, cracks will appear in the veneer and inlays become loose. When the glue holding them down fail, veneers lift. Causes polishes to shrink, craze and flake.

High RH

Swelling can cause moving parts such as cabinet doors or drawers to jam. If glue fails, veneer peels away. Corrosion affects nails holding things in place, metal inlay and fillings. Insects and rot may flourish as the content of the wood rises, fast and constant cycling of RH fluctuations causes the most damage for all the above to create rapid structural weakening.

The Role of HVAC

Low Indoor Humidity: Is generally experienced in areas that are very cold in the winter or very hot in the summer. In cold areas the indoor air is heated, and the moisture goes up the vent pipe, depriving wood objects of the humidity

required for a healthy moisture content. Whole house humidification systems are the most efficient way to prevent dry wood damage to floors, cabinets, musical instruments, doors, molding & millwork. The addition of moisture will make the heating system far more efficient as well.

High Indoor Humidity: Is generally seen in the summertime in many areas of the country where outdoor relative humidity gets very high. Air conditioning will remove a great deal of humidity from indoor air. However, this works the air conditioning unit very hard and in most areas air conditioning levels are set in the 60's to remove enough moisture for the room to be comfortable. Dehumidifiers can be added to the HVAC system to take a lot of the strain off an air conditioning unit. Dehumidifiers are much less expensive than air conditioners, and dehumidifiers can make the air conditioner last longer and be far more energy efficient.

Homeowners need to be aware of the vital role that relative humidity plays in wood performance. Not just flooring but anything made of wood found in a home, including the structure itself.

Pre-Installation Inspection

VISUAL INSPECTION

The first inspection is visual and basic. Is there water/moisture in the building? Are the doors and windows installed and the building weather tight?

INSTALL FLOORING LAST

Hardwood floor should be the last trade in the house (before base boards are installed). All concrete, masonry, plastering/drywall, texturing, and painting/ primer coats should be completed beforehand. Covering the floor while wet trades are in the house can lead to moisture condensation on the protective paper. Moisture can pull into the paper or be trapped under the surface of materials used to cover the floor. Paper coverings also allow dents and scratching to occur. Coverings held in place for more than 24 hours by blue tape can damage the floor. The adhesive in many tapes contain Phthalates / plasticizers that can penetrate floor finishes and bond with the finish at the molecular level presenting a risk of pulling/ damaging the finish when the tape is removed. Monogram recommends that built-in cabinets and built in furniture be installed before installation of the

floor. This prevents damage to the flooring and makes any potential flooring repairs that may be required later simpler to perform.

WARNING COVERING WITH PAPER OR CARDBOARD

Floors are most often installed too early, without climate control, and other wet trades are present in home. Paper and cardboard often absorb moisture further damaging the finish.

Exterior Checks

1. Proper drainage away from the structure is critical to ensure weather-tight conditions and crucial to proper hardwood flooring performance. If the structure is near a hill, the lot should be graded with a swale to move moisture off the lot and prevent it from coming in contact with the foundation.
2. Is exterior soil elevation 6" below the edge of flashing?
3. Is exterior hardscape (concrete, wood decks, pavers) elevation at least 2 ½" lower than edge of flashing and door thresholds?
4. Does exterior slope away from foundation at a rate of 6" drop in 10' for soft landscaped areas and 3" drop in 10' for hard-paved areas?
5. Rain gutters should be in place to carry moisture away from the house. French drains are recommended, and basement walls should be properly sealed.

Basement Moisture & Humidity Control

Basements should be completely weather tight and have proper drainage away from the foundation walls in place to ensure that the basement remains dry.

1. Basement should be free of all moisture and be weather tight.
2. Relative humidity of basements should not be more than 10% higher than the upper floors.

3. Humidity control of the basement is vital to help control mold and prevent damage to the structure and hardwood flooring.

4. Basement walls should be inspected for cracks and excessive moisture content.
5. Drains must be placed at basement windows.
6. Direct sprinklers and irrigation systems away from the foundation. Sprinklers spraying the foundation edge can lead to moisture intrusion into structure. Drip irrigation systems for plant beds is recommended.

Crawl Space Ventilation

Crawl space earth (or thin concrete slab) should be covered 100% by a vapor retarder of polyethylene (minimum 6 mil) or any recommended puncture resistant membrane, such as Class C meeting ASTM D1745. Check local codes or any additional requirements.

Size of available vents should equal to 1.5% of the square footage within the crawl space. Relative humidity should be consistent with the interior of the home.

Moisture content of sub floor should not vary more than a 2% MC from the top of the sub floor to the bottom.

It may be necessary to install temperature/ humidity activated exhaust fans to create more air movement in the crawl space. Uncontrolled humidity and moisture in crawl space may lead to mold and damage to the structure, as well as the hardwood floor. In these events, a contractor specializing in dehumidifying systems should be contracted to keep crawlspace humidity within proper norms. This is more likely in high humidity areas.



NOTE: In completely sealed crawlspaces (no exterior cross-ventilation) require a dehumidification system

as part of the sealed crawlspace design

Sub floor Moisture Testing CONCRETE

Since wood flooring is not compatible with wet conditions, Monogram Floors does not warrant moisture related issues or related damage under warranty. This is an industry standard; manufacturers do not offer moisture warranties. However, moisture warranties are offered by various adhesive manufacturers.

NOTE: Due to the porous nature of concrete, vapor emissions are subject to change over the lifetime of the installed floor. Slab moisture emissions are a common cause of damage to hardwood floors. Due to the potential for concrete moisture emissions to increase/decrease over time, and the absence of moisture warranties for wood flooring, choosing an adhesive system that includes moisture abatement properties is prudent.

ADDITIONAL NOTE: Monogram Floors make no guarantees regarding the performance of any adhesive/vapor abatement system. The installer is fully responsible for proper installation, and the moisture warranties are fully the responsibility of the manufacturer of the adhesive moisture abatement system.

NWFA Moisture Testing Standards

The NWFA (Industry standard) uses the following test methods to determine optimal conditions for installation and performance of a hardwood floor. Follow adhesive manufacturers specifications for testing of concrete subfloor.

CALCIUM CHLORIDE: ASTM F1869

Under ideal conditions, the slab should not be emitting more than 3 lbs. per 1,000 square feet per 24-hour period. Carefully follow the instructions in the test kit to ensure that you get accurate results.

HUMIDITY PROBE & DIGITAL METER: ASTM F2170

Widely used in Europe, this test determines the amount of humidity in the slab. This is an effective way to determine a slab's potential for emitting moisture.

Follow all meter manufacturer's guidelines for performing testing. Under ideal conditions, the slab readings should be 75% RH.

CAUTION: Post Tension Slabs require special care to avoid cutting cables in slab. Cutting post tension cables can cause serious structural damage and potential fatalities.

New concrete slabs require a minimum of 60 days drying time before covering them with a wood floor. The slab must be fully cured. Slab must be comprised of Portland-based mix with a minimum of 2,500 PSI of compressive strength.

Sub floor Preparation CONCRETE

For glue down application over gypsum or lightweight concrete, the same 2,500 PSI min. rating is required. (See floating installation section for installation over lightweight substrates).

Note: Some adhesive systems have primers and adhesives that are suitable for use over gypcrete or lightweight concrete and may have different PSI compressive strength requirements. Adhesive manufacturers are responsible for the performance of their systems over gypcrete or lightweight concrete.

Remove all paint, oil, existing adhesives, wax, grease, dirt, sealers, and curing compounds. Do not use solvent-based strippers under any circumstances, as residual solvents can prevent the satisfactory bonding of the vapor barrier and adhesive systems. It is important to ensure a long-lasting bond between the adhesive, the concrete, and the boards. FOLLOW ALL ADHESIVE APPLICATION INSTRUCTIONS.

Industry standard practice is to use a sanding system with 20 grit, #3½ open face paper to remove loose, flaky concrete. For heavy surface contamination, it may be necessary to bead blast the concrete surface.

NOTE: Adhesive manufacturers generally recommend prep fillers and patches to repair concrete substrates that are compatible with the adhesive system to be used. Make sure you use the prep products that are recommended by the adhesive manufacturer.

Sub floor tolerance for a flat surface is 3/16" within a 10' radius and 1/8" in a 6' radius. These are industry standards established by NWFA. Use a straight edge

to determine if sub-floor requires grinding or filling.

NOTE: A quarter is approximately 1/16" thick and can be used as a thickness gauge. Grind high spots and fill low spots with adhesive manufacturer's recommended filler.

REMINDER: Use the filler recommended by the adhesive manufacturer.

California Prop 65 Warning

Drilling, cutting, and grinding of concrete generates concrete dust, containing crystalline silica, a substance known to the State of California to cause cancer, birth defects, or other reproductive harm. Avoid inhaling concrete dust by wearing a dust mask or other safeguards for personal protection.

CA HEALTH & SAFETY CODE 14808-60-7:

Wear an appropriate NIOSH designated dust mask to reduce risk of dust inhalation. Wear proper eye protection and avoid prolonged contact with eyes and skin. In the event of eye irritation, flush with water for 15 minutes and seek medical attention!

CAUTION: ASBESTOS

State and Federal agencies have determined that asbestos is a respiratory carcinogen. Avoid sanding or scraping of old vinyl, linoleum and VCT as they may contain asbestos. Take proper precautions and contact an asbestos abatement company to remove any old vinyl or vinyl tile floors containing asbestos. Cut-back adhesive and other types of adhesives can also contain asbestos.

Clean the Sub floor

After all prep work is completed, sweep and/ or vacuum the sub floor. Dust and dirt can affect the adhesive or vapor barrier's ability to adhere to the slab.

Installing over Existing Floor Coverings on Concrete

Perimeter-glued resilient vinyl, VCT and rubber tiles are not acceptable underlayment's and must be removed. Terrazzo, tile, and full spread glue-down vinyl's that are dry, structurally

sound, and level (as described above) may be suitable as a subfloor for installation.

See adhesive manufacturer's guidelines. Monogram is not responsible for performance or suitability of existing flooring products that are not removed. As indicated above, the surface must be sound, tight, and free of paint, oil, existing adhesives, wax, grease, and dirt. Terrazzo and ceramic tile must be sufficiently scuffed to assure adhesion. Portland based products must be used to comply with flatness requirements of 3/16" in a 10' radius or 1/8" in a 6' radius. See adhesive manufacturer's guidelines.

Existing vinyl, tile, or terrazzo are not considered to be vapor barriers, and can still transmit unacceptable moisture levels to hardwood flooring. Existing hardwood flooring must be removed prior to the installation of a new wood floor on concrete.

Sub floor Moisture Testing WOOD

Probe-type (pin) meters are considered the best method of testing. Remember: the top and bottom of the sub floor should vary no more than 2%.

Wood substrates must have a moisture reading of no more than 12% when using Lignomat, Tramax, Delmhorst, or equivalent moisture meter, and be within 4% of the moisture content of the flooring to be installed.

Sub floor Preparation WOOD

Wood subfloors need to be well nailed or secured with screws. Nails should be ring shanks, and screws must be counter-sunk. The wood sub floor needs to be structurally sound (i.e., without loose boards, vinyl, or tiles).

Subfloor tolerance for a flat surface is 3/16" within a 10' radius and 1/8" in a 6' radius. These are industry standards established by NWFA.

Engineered subfloor panels, must be ANSI-rated plywood, OSB (oriented strand board) of specified

thickness to meet joist spacing specifications listed below, or sound, solid lumber subfloor that is a minimum of 3/4" thick and dry.

1. For panel products subflooring, check for loose panels and re-nail or screw down loose panels securely. Nails and screws must be countersunk.

2. Ensure that there is proper expansion space (1/8") between the panels. If panels are not tongue and groove and do not have sufficient expansion space, it may be necessary to use a circular saw to create the specified space. Do not saw through joints on tongue and groove sub floors.

3. Check for delamination or damaged areas to sub floor and repair those areas as needed.

4. Make sure the subfloor is free of debris before beginning installation.

5. Acceptable Panel Subfloors: Truss/joist spacing will determine the minimum acceptable thickness of the panel sub flooring.

Truss/Joist Spacing

a. Truss/joist spacing of 16" (406cm) o/c or less, the industry standard for single panel sub flooring is a minimum of 5/8" (19/32", 15.1mm) CD Exposure 1 plywood sub floor panels or 23/32" OSB Exposure 1 sub floor panels, 4' x 8' panels.


b. Truss/joist spacing of more than 16", up to 19.2" (488mm) o/c, the standard is a minimum 3/4" (23/32", 18.3mm) tongue and groove CD Exposure 1 Plywood 4' x 8' sheets glued and mechanically fastened or 3/4" (23/32", 18.3mm) tongue and groove OSB Exposure 1 subfloor panels, 4' x 8' sheets glued and mechanically fastened.

c. Truss/joist spacing of more than 19.2" (488mm) o/c up to a maximum of 24" (610mm) requires a minimum 7/8" tongue and groove CD Exposure 1 plywood sub floor panels, 4' x 8' sheets, glued and mechanically fastened, or nominal 1" OSB Exposure 1 sub floor panels glued and mechanically fastened—or two layers of subflooring.

NOTE: Subfloor deflection is the number one cause of squeaking in nail-down floors. If subfloor deflection exists corrective measures must be taken to correct it, even if the subfloor thickness meets industry specifications for thickness of subfloor in relation to joist spacing.

JOIST CROSS-BRACING

A sub floor that is not thick enough to support the span of the joists will cause unacceptable subfloor deflection. An alternative to adding additional plywood on top of the subfloor would be to cross-brace between the joists. The cross-bracing would be done at the appropriate distance on center to meet specification and bring the deflection within proper tolerance.




Check with the joist or truss manufacturer to determine if cross-bracing is allowed with that system. Should it not be compatible with the joist or truss manufacturer, sheeting the sub floor with a second layer of CD or better grade plywood would then be the only option. (See double-layer sub floors section).

DIRECTION OF INSTALLATION IN RELATION TO JOIST POSITION.

The best application is at a 90° angle across the joists. This provides for best stability of the floor. As an alternative, the floor can be installed at a 45° angle to the joists. The floor cannot be installed in the same direction as the joists without installing an additional sheet of plywood on top of the existing wood subfloor. Installing the same direction as the joists without reinforcing the subfloor is common cause of squeaking in a nail down floor.

When installing the flooring in the same direction of the joists, a second layer of plywood is required to stiffen sub floor. Subfloor must be sheeted with 1/2" (15/32", 14mm) CD exposure 1 plywood sub floor panels. Use same method as attaching to solid board subflooring.



SHEETING EXISTING SUB FLOORS

SOLID BOARD SUB FLOORING

Solid Board Subflooring should be 3/4" x 5 1/2" (1" x 6") group 1 dense softwoods (SYP, Doug Fir, Larch, etc.), #2 common, kiln dried. Solid board subflooring should consist of boards no wider than 6", installed on a 45° angle, with all board ends full bearing on the joists and fastened with a minimum 8d rosin-

coated or ring-shanked nails, or equivalent. Solid board subflooring that is uneven at the edges should be repaired and sheeted with ½" (15/32", 14mm) CD exposure 1 plywood subfloor panels, 4' x 8' sheets, and should be installed running cross-truss/joist. Glue top and bottom layer together with construction adhesive and screwing into the truss/joist system every twelve inches.


Additionally, nail (ring shank) or staple layers together on a minimum 12" grid pattern. Sheets should be glued to lumber subfloor using good quality construction adhesive and screwed to joists. Sheeting must be nailed or stapled to sheeting.

When the subfloor does not meet thickness standards for span between joists, a second layer of plywood is required to stiffen sub floor. See item C of previous section.

The minimum second layer should consist of nominal ½" (15/32", 11.9mm) CD exposure 1 plywood sub floor panels, 4' x 8' sheets, depending on how much correction of deflection between joists is necessary. A thicker layer may be required to offset joist spacing.

The top layer of plywood should be offset by 2' from joints in first layer of subfloor and installed in the opposite direction to the bottom sub floor panels. Glue top and bottom layer together with construction adhesive (specified as suitable for this use) and screwing into the truss/ joist system every twelve inches. Additionally, nail (ring shank) or staple layers together on a minimum 12" grid pattern.

GENERAL INFORMATION: No fiberboard or particle board are acceptable for nail down installation. Underlayment/industrial grade particle board sheeting over existing wooden subfloor is usually suitable for glue down applications. See adhesive manufacturer's specifications to ensure adhesive is suitable for use over underlayment/industrial particle board sheeting.



Countersink all screws/ nails and sand any uneven edges smooth. High spots should be sanded smooth and low spots shimmed with plywood that is secured to the sub floor and sanded flat.

CEMENTITIOUS PATCH - WOOD SUB FLOOR

Do not use cement-based patch to correct any wooden sub floor problems in preparation for nail down. In the event of moisture, determine the source, eliminate, and allow subfloor to dry. If subfloor is less than above specified thickness or sanded to thickness less than specified see the above standards for top sheeting.

NOTE: Particle board sheeting of existing wood sub floor and Portland based leveling compounds are acceptable for glue-down or floating applications only (they are NOT suitable for nail- down applications). See adhesive manufacturers specifications for installation over particle board. Not all adhesive manufactures allow glue down to particle board.

EXISTING WOOD FLOOR - ON WOOD SUB FLOOR


When installing over an existing solid hardwood floor already attached to the wood sub floor, ensure that the existing floor is sound and firmly attached to sub floor. Install material at a 90° right angle or 45°angle (across grain) of existing hardwood floor.

NOTE: Do not install in the same direction as existing floor. Do not install over wood flooring glued to concrete.

In- Floor Radiant Heat – Hydronic & Electric / Engineered

Radiant Heat - Hydronic

Subfloor level tolerances listed previously, also apply to radiant heated subfloors



Conceptual Drawing

CLASSIFICATIONS OF HYDRONIC SYSTEM


- Encased in Cement/Gypcrete
- Encased in Aluminum Hangers, between flooring joists involve the use of Aluminum Transfer sheets between subfloor and a wood deck between sleepers.
- Surface tubing with Aluminum pressed into surface slots (i.e., Warm Board). Direct contact by tubing with back of floor is not allowed outside of the Warm Board system or comparable, using a 2mm premium underlayment.
- Note: No system in direct contact with the floor without aluminum is permitted.

PERMITTED APPLICATION METHODS

- Glue Down
 - Floating Installation
- Note: No nailing permitted. Risk of punctured tube, or nail acting as a thermal sink create undue hazard to floor.

Radiant Heat – Electric

Sub floor level tolerances listed previously, also apply to radiant heated subfloors.



Conceptual Drawing

CLASSIFICATIONS OF ELECTRIC SYSTEMS

Encased in Cement/Gypcrete/Mortar Low Voltage Fabric Heating Mat with Thermal Cut Off NOTE: Other electric systems include, plastic mat, fabric mat., metal mesh mat, and are not recommended.

PERMITTED APPLICATION METHODS

- Glue Down
 - Floating Installation
 - Nail Down
 - Glue Assist Nail Down(glue mat first)
- NOTE: Fabric Heating Mat with Thermal Cut Off, designed to be installed at the same time as the flooring. Make sure structure is dry, and 60 to 80° F with RH of between 30 to 55%. NOTE: Hickories to be maintained at 35-55%.

HYDRONIC RADIANT HEAT APPROVED PRODUCTS

All (excluding Hickory)

CAUTION: Surface temperature of the wood floor should never exceed 80° F. Temperature sensors must be integrated into the system as a failsafe to prevent excessive heat and damage to the hardwood floor.

NOTE: Area rugs and closed bottom furniture placed over radiant heat system will create heat retention in the floor. This may result in that area exceeding optimum temperature and causing slightly larger gaps and minor cracks/splits in the floor under closed bottom furniture (bookcases, entertainment units, area rugs etc. Hydronic systems are difficult to regulate in that regard.

INSTALLATION METHODS-HYDRONIC

Floating Installation: Monogram recommends the use of a premium underlayment pad. The tongue and groove must be glued together using White PVA-D3 (poly vinyl acetate) tongue and groove adhesive.

GLUE DOWN CONCRETE THERMAL MASS / RADIANT HEAT

Adhesive must be approved by adhesive manufacturer for use with radiant heat. Adhesive system must employ a vapor control component designed to be used in conjunction with the adhesive by the adhesive manufacturer.

Thermal mass must be Portland based concrete product and rated at a compressive strength of 2500 psi or greater. Thermal mass with less than 2500 psi compressive strength must use floating installation method unless otherwise specified by adhesive manufacturer.

Hydronic warm water systems installed in accordance with NWFA specifications are acceptable. Tubing must be a minimum of 1 1/4" below the surface of the concrete thermal mass.

NOTE: Gypcrete, some adhesive manufacturers have methods for gluing to Gypcrete thermal

Due to performance, compatibility and safety considerations, only systems compliant with the NWFA Guideline classification of Fabric-Heating Underlayment or Mat with Thermal Cut Off are recommended for direct contact with Monogram Flooring. All other system variants require installation of the heating components either between joists or embedded in a 1" thermal mass of cement with the flooring when installed according to the installation instructions.

In-floor systems powered by FiberThermics® such as WarmStep® and ThermoFloor® are classified as Fabric-Heating Underlayment or Mat with Thermal Cut Off and are approved for direct contact.

ELECTRIC RADIANT HEAT APPROVED PRODUCTS

All (excluding Hickory)

CAUTION: Surface temperature of the wood floor should never exceed 80° F. Temperature sensors must be integrated into the system as a failsafe to prevent excessive heat and damage to the hardwood floor.

NOTE: Area rugs and closed bottom furniture placed over radiant heat system will create heat retention in the floor. This may result in that area exceeding optimum temperature and causing slightly larger gaps and minor cracks/splits in the floor under closed bottom furniture (bookcases, entertainment units, area rugs etc. Mat heating systems can be spaced to eliminate heating under heat traps.

FLOATING INSTALLATION / RADIANT HEAT

Monogram recommends using a premium underlayment pad.

The heating mat to be placed on top of the 2mm underlayment pad. The tongue and groove must be glued together using White PVA-D3 (poly vinyl acetate) tongue and groove adhesive.

In- Floor Radiant Heat – Hydronic & Electric / Engineered

mass. Follow adhesive manufacturers guidelines for installation. Additional Note: some adhesive manufacturers require the use of a primer on Gypcrete.

RADIANT HEAT IN LIGHTWEIGHT CONCRETE- DRYING THERMAL MASS PRIOR TO INSTALL

Two to three weeks prior to the arrival of the hardwood floor and after completion of all wet work at the job site, the radiant heat system should be on at a temperature of 70° F for three weeks and then at 85° F for 2-3 days. During this time, the structure should be well ventilated to prevent moisture buildup (the increased heat is driving the moisture out of the concrete thermal mass during this time). If this is not possible due to weather/ outdoor climate conditions, dehumidifiers should be used to keep moisture from building up in the structure.

NOTE: Prior to installation, the lightweight concrete moisture content must not exceed 1.5% as measured with a Tramax meter. Check adhesive manufacturer's requirements as they may be different, or they may be incompatible with the hydronic tubing.

INSTALLATION METHODS-ELECTRIC

Electric Fabric-Heating Underlayment or Mat with Thermal Cut Off: Can be installed in multiple ways. Lower heating element temperatures are possible since the spacing of the heating element is 3" apart. System is designed to be in direct contact with the back of the wood floor.

Glue-Down: Method can be used on specified electric systems. First gluing pad to subfloor and then gluing floor to top of pad.



Floating: Method can be used on specified electric systems, utilizing a high-quality underlayment pad, as specified by the type of system being used. Over concrete and a 2mm pad is used under the heating mats powered by FiberThermics® heating elements.



The tongue and groove must be glued together using White PVA-D3 (poly vinyl acetate) tongue and groove adhesive.



Nail-Down: Is permitted when using heating mats powered by FiberThermics® heating elements. Elements are yellow and spaced three inches apart.

Glue-Assist: Nail-Down: Is permitted when using heating mats powered by FiberThermics® heating element.

HYDRONIC RADIANT HEAT / WOOD SUBSTRUCTURE AND ALUMINUM THERMAL TRANSFER SHEET/HANGERS – PRIOR TO INSTALL

Two weeks prior to arrival of hardwood flooring at job site, the radiant heat system should be gradually brought up to 70° F. Moisture levels allowable in wood sub floor are not to exceed 12%. Once systems have reached optimum conditions, Hallmark Floors engineered hardwood flooring should be brought to job site, not before.

WOOD FLOOR ACCLIMATION PROCESS FOR ELECTRIC RADIANT HEAT

Monogram Floors engineered hardwood flooring is dried to a moisture content of approximately 8% -10% moisture content by volume. This is a stable moisture content, and it is important to adjust the indoor climactic conditions to fully support the moisture content found in the boards. A relative humidity rating of 30 to 55% (hickory products should be maintained at 35-55%) at time of installation and lifetime of floor is required.

Allow unopened boxes of Monogram Floors engineered hardwood flooring to stabilize in above environment for 24 to 48 hours to allow material to adjust to room temperature. Room temperature should not vary more than 15° F season to season and relative humidity range between 30% to 55% should be maintained (Hickory products are to be maintained at 35-55%).

ELECTRIC: Since the heating mat with thermal cut-off is being installed at the same time as the floor it eliminates pre-running the system. Preheat the room to 10° F below desired room heat. Set floor thermostat to 5° F above its current temperature, and increase 5° F daily, until desired thermal comfort is achieved.

NOTE: Air temp and floor temp are different numbers and the floor temp can be kept cooler than the desired air temperature as thermal warming is more efficient and comfortable.

Below Grade Installation

A concrete slab is considered below grade when any part of the slab is below ground level. For example, a basement with a walk out is considered below grade. A house cut into a hill is also considered to be below grade if it isn't properly graded to create a drainage swale on the lot. Below grade slabs must be carefully tested. Diligently follow all adhesive or underlayment pad manufacturer's instructions for below grade installation. Nail down installation is not suitable for below grade installation.

Getting Started

1. ABOVE GRADE WOOD SUB FLOOR: Glue, Nail, Float

BASEMENT: Glue with vapor abatement system (follow adhesive manufacturer's instructions for below grade installation).

Float: follow underlayment pad manufacturer's instructions for below grade installation.
NOTE: No solid installations in basements.

WOOD SUB FLOOR WITH CRAWL SPACE/ BASEMENT:

Glue, Nail, Float

ON/ABOVE-GRADE CONCRETE: Glue, Float

ABOVE GRADE LIGHTWEIGHT CONCRETE

GYPCRETE: Float, Glue (see adhesive manufacturer's installation instructions for lightweight concrete/ gypcrete installations).

RADIANT HEAT: Float, Glue


NOTE: Floating systems must use good quality underlayment pad with moisture barrier. If using over radiant heat, make sure pad Manufacturer authorizes their product for radiant installations.

2. Cabinets & Appliances

NAIL DOWN & GLUE DOWN: Cabinets and built in appliances (sub-zero refrigerators & dishwashers) should be installed prior to the installation of the hardwood floor. **Cabinets and built-in appliances should not be installed on top of the floor.**


Installation of cabinets on top of nail-down or glue down floors can contribute to squeaking

objectionable noise in floor Installation of cabinets on top of glue or nail down installation does not invalidate warranty. However, since this is not best practice, should the floor require repair under warranty, Monogram Floors will not be liable for costs to remove and replace cabinets and or counter tops to effect repair.



FLOATING: Cabinets and built-in appliances **should never be installed on top of the floating wood floor.**

Floating floors require unhindered expansion space in all directions. Installation on top of floating floors can contribute to buckling, bounce, squeaks, and objectionable noises.




Hardwood flooring should be installed at the same time as carpet and after the following: finishing walls, cabinet installation, appliance installation, tile & countertop installation.

Standard refrigerators and kitchen oven/range are acceptable for placement on top of the wood floor. Use caution when moving appliances by using a proper furniture dolly, air sled, 1/8" Masonite with glossy side down, or plastic glides designed for movement of heavy appliances. Failure to follow these precautions will damage the floor.


3. Undercut All Door Jambs/Moldings

Remove all shoe and base molding to ensure adequate expansion space. Use scrap piece of flooring to establish height of cut. Make allowances for adhesive or underlayment thickness when establishing height of cut.



4. Visual Inspection of Boards

Visually inspect boards for any defects prior to installation. Verify that homeowner has seen product and approves/authorizes proceeding with installation of the floor.



5. Work From Multiple Boxes

Always work from multiple boxes simultaneously and blend the boards throughout the installation. This is especially important with mixed production dates. Monogram has very good color consistency, and mixed production dates are acceptable for installation. Working from multiple boxes/production dates helps achieve a good blend of color.

6. Pre-Blend Boards to Moldings

check how the boards blend with the moldings. At beginning of installation, set aside those boards that best blend to the transition moldings on job.

7. Select a Starting Point


It is recommended to start the installation along an exterior wall. Check to make sure the wall is straight and square to the room. If floor installation starts in center of room establish a straight line.

8. Starting Line Expansion Space Side & Ends

Cut blocks to use against side and end walls to maintain 1/2" minimum expansion space. Use of adjustable spacers may be needed to help maintain a straight line.


9. Establishing End Joint Spacing

Applicable for all three methods of installation (glue-down, nail down, float). Each box contains random length boards. Use these boards as well as making some random cuts to establish a random pattern. Maintain a minimum distance/stagger between end joints of 6-8".



10. Change of Direction

GROOVE TO GROOVE, USING A SLIP TONGUE/ WOOD SPLINE:



Slip-tongue/wood-spline can be fabricated using birch plywood, cut into strips on a table saw. Cut width to 5/16" wide to allow room for glue once inserted. The following thickness of Baltic Birch plywood should be used to fabricate wood spline for the following thickness of Monogram Flooring:


3/8" = 3mm or 1/4"

1/2" = 4mm or 5/32"

9/16" = 4mm or 5/32"

5/8" = 5mm or 3/16"

3/4" = 6mm or 1/4"



Note: Sand corners of spline with sanding block and 60 grit sandpaper to soften/round the edges (all four sides).

Installation Alert

Do not use rubber mallets or hammers on the finished edge of the floors. Do not kick, the floor into place. Mallets, hammers, and shoes used to kick the floor into place can damage the finished edge and can scratch the floor.


General Information

NOTE: Follow instructions 1-11 and all directions listed below.

Glue Down Installation


12 GD.

Remove Tongue & Lead with Groove - Cut off the tongue on the very first row to be installed and lead with the groove. This enables the tongue to be partially inserted into the groove before coming into contact with the adhesive.



13 GD.

Starter Rows - Measure the equivalent of four to five rows, mark subfloor at both ends of the run and snap a chalk line. Spread adhesive to chalk line. Repeat this process on all subsequent rows of material throughout the balance of installation.




14 GD.

Strap Starter Rows - Once starter rows are installed up to chalk line/edge of adhesive bed, strap across the grain. Allow adhesive to set up long enough to have a firm hold. Use the flat side of the trowel to flatten any adhesive at edge of the leading board. Once the boards are firmly seated, proceed to work across the floor. **CAUTION:** Do not let boards open or drift off straight line.


15 GD.

Check Straight Lines - Run string along joint lines to check if you are wandering offline and use caution to keep all end and side joints closed. The edge of a 6' level or straight edge along the leading rows can also help determine the maintenance of a straight line.



16 GD.

Trim Last Row - Cut the last row and snug into place using a pull tool.



17 GD.

Install Transition Moldings Install moldings using urethane glue or high-quality adhesive. It may be necessary to place weight on edge to ensure molding level is flush with flooring.


Nail Down Installation

General Information

NOTE: Follow instructions 1-11 and all directions listed below.

Proper placement of fasteners is critical to the performance of the floor. Overshooting the fastener weakens the tongue and the damage can telegraph to the surface. Care must be taken not to damage the edge of the plank with mallets or the edge of the nail gun. Improper placement will create a noisy floor.

Air Pressure Settings



Approved Nail/Staple Systems

- ✓ **POWER NAIL AIR DRIVEN MODEL 50P Flex**
18 gauge, Cleat 1 ½". Use 12 oz. rubber hammer to activate gun. Gun adjusts to nail 3/8", 7/16", ½", 9/16", 5/8"
- ✓ **POWER NAIL AIR DRIVEN MODEL 50F**
18 gauge, Cleat 1 ½". Trigger activated
Gun adjusts to nail 3/8", 7/16", ½", 9/16", 5/8"
- ✓ **POWER NAIL AIR DRIVEN MODEL 200**
20-gauge/e-cleat 1 ½". Use 12-oz. rubber hammer to activate gun. Gun adjusts to nail 3/8", ½", 9/16", & 5/8"
- ✓ **PRIMATECH AIR DRIVEN MODEL Q550R**
Adjustable base plate and surface rollers 18 gauge, L cleat x 1 ½" Use 12 oz. rubber hammer to activate gun. Adjusts to nail 3/8", 7/16", ½", 9/16", & 5/8"
- ✓ **PRIMATECH AIR DRIVEN MODEL 180**
Adjustable base plate and surface rollers 18 gauge coated staple, 1/4" crown. Trigger activated. Gun adjusts to 3/8", 7/16", 1/2" 9/16", 5/8"
- ✓ **HIGHPRO AIR DRIVEN MODEL 4590T**
18 gauge coated staple, ¼" crown x 1 ½" Leg. Trigger activated. Gun adjusts to nail 3/8", 7/16", ½", 9/16" & 5/8"
- ✓ **BOSTITCH AIR DRIVEN MODEL EHF1838K**
18 gauge coated staple, ¼" crown x 1 ½" Leg. Trigger activated. Gun adjusts to nail 3/8", 7/16", 9/16", & 5/8" Not approved for installing 3/8"
- ✓ **PORTA NAIL AIR DRIVEN MODEL 461A**
18 gauge coated staple, ¼" crown x 1 ½" Leg. Trigger activated. Gun adjusts to nail 3/8", 7/16", 1/2", 9/16" & 5/8".

ONLY USE RECOMMENDED FASTENER SYSTEMS APPROVED IN THESE INSTRUCTIONS!

NOTE: REGARDING NOISY FLOORS:

Squeaking/noisy floors are invariably related to movement. The movement is commonly associated with deflection of the subfloor. Many times, too much deflection exists in the subfloor between the joists. Sag between the joists is

another common cause of objectionable noises from the floor.

Incorrect placement of a fastener (improper nail-gun shoe adjustment, incorrect air pressure), incorrect spacing, incorrect size of fastener (too short, too long, uncoated staples, too heavy a gauge) are very often the cause of noise.

Lack of expansion space, installing cabinets and built-ins on top of the floor, and incorrect climate conditions (swell of planks), poor quality subfloor (OSB or Plywood that have gotten excessively wet during construction) loose strength and may be unable to properly hold a fastener, as well as lack of proper underlayment all cause movement related noise.

Monogram Floors adhere to all NWFA/NOFMA standards for milling tolerances at time of manufacturing. Excessive swelling or shrinking related to adverse environment can affect milling tolerance.

Objectionable noise is not related to a manufacturing defect and expressly excluded from warranty.

NOTE: Any defects in milling must be determined in the first 10% or 100 sq. ft. (whichever is less) of the floor being installed. If milling is to industry specifications and instead is related to installation or site related issues the material will not be eligible for replacement.

12 ND. Underlayment SPECIFIED UNDERLAYMENTS


15 to 30 lb. roofing felt when doing a nail-down installation. Staple in place and then proceed to install the floor.

Aquabar "B" Hardwood Floor & Tile Underlayment. Staple in place and then proceed to install the floor.

Allglobe -Silicone Vapor Shield. Staple in place and then proceed to install the floor.

CAUTION:

Red Rosin or craft paper is not an accepted underlayment. Foam underlayment pads are not acceptable for nail down. Elimination of underlayment's in



favor of running beads of construction adhesive to increase the holding power to the sub floor has some risks. Underlayment's have always acted as a vapor inhibitor. Without the underlayment, the floor is subject to cupping and crowning from moisture intrusion from the subfloor.

13 ND. Starter Rows:

Nail-down method requires that installation be done by leading with the tongue. When starting at the wall, trim groove off the back of the boards being used for the starting row. Face nail the back edge of the board with 18-gauge nails, then blind nail into the pocket above the tongue with one of the above approved nails/ staple systems. As face nailing is accepted practice, face nailing the boards as far back as possible can help hide the face nailing under the base and quarter round/ base shoe. It may be necessary to blind nail the tongues of the starter boards to eliminate any surface nail holes until far enough from the wall to use floor nailer.

14 ND. Nail/Staple Spacing

Nail/staple spacing needs to be 4" to 6" apart and within 2" of board ends. Installer should be standing directly on top of the board being nailed down. This ensures the bottom of the plank is firmly seated on the sub floor. Check regularly to ensure the plank is snug to the sub floor. Any gap between the bottom of the plank and the sub floor is a source for squeaking. Warning: Nailing too close to end could fracture the corner of the plank.

15 ND. Check Straight Line

After three rows of flooring have been installed, take a six-foot level, and check the leading edge to be sure floor is on a straight line. Lay the level on its back and glide bottom edge along the tongue. Failure to stay on a straight line will cause irregular gaps in floor on sides and ends.

16 ND. Trim & Face Nail End Rows

Cut the last row and snug into place using a pull tool. Face nail the remaining rows with 18-gauge nails. It will be necessary to face nail the remaining rows when the blind nail gun is too close to the wall to fasten down the planks.

Special Instructions Nail Down Glue Assist

GENERAL INFORMATION NOTE:

Follow instructions 1-11 and all directions listed below.

The following is an addendum to the nail down section. This installation method has gained popularity with the increase in the width of planks over the last decade. The underlying risk in this method is that the vapor barrier sheet is now missing from the surface of the subfloor.

The vapor barrier sheet can now be replaced by roll on vapor retarders for use in glue assist. We do not recommend this method for regular nail-down applications without glue assist.

A moisture imbalance in the bottom of the plank, due to a lack of moisture control, combined with drier air in the room above can cause moisture related damage to the floor.

Monogram Floors, like the entire wood flooring industry, has no warranty against moisture related issues with the floor.

1 ND/GA. Subfloor Deflection.

The primary cause of squeaking floors is related to subfloor deflection/subfloor movement, between the joists. Even if the subfloor is the proper thickness to meet specifications, this can still be an issue due to the subfloor not having enough tensile strength to perform to industry specifications.

2ND/GA. Subfloor Moisture - CAUTION

Moisture intrusion or exposure to moisture is not covered under the warranty. This is true of all subfloor types and installation methods.

3ND/GA. Roll on Vapor Retarders

Glue-assist nail-down cannot be performed using traditional vapor inhibitors such as 15 lb. roofing felt or Aquabar.


Roll on vapor retarders are now available to replace traditional vapor inhibitors such as 15 lb. roofing felt or Aquabar. Follow all directions from the manufacturer of the Roll-on Vapor Retarder used. The use of Roll-on Vapor Retarder has been reported to improve the adhesion of the bead of flooring

adhesive described in 4 ND/GA.

NOTE: Unfinished basements or uncontrolled crawl spaces may expose the subfloor and the plank itself to elevated moisture contents that will cause excessive expansion of the floor. Finished basements and enclosed crawl spaces with proper humidity control are required for all structures with a wood subfloor

4ND/GA. Glue Type & Application Method

Multiple flooring adhesive manufactures produce adhesives in plastic casings, that are inserted into an application gun. Place the size of bead of adhesive on the back of the planks, recommended by the adhesive manufacturer. Apply adhesive in a serpentine pattern on the back of the plank. Apply plank to surface and attach to floor using nail down installation method.



RETURN TO NAIL DOWN INSTRUCTIONS AND PROCEED.


Floating Installation

GENERAL INFORMATION NOTE:

Follow instructions 1-11 and all directions listed below. Installation Tools FLOAT Tape measure, pencil, chalk line, table saw, cut-off saw, jamb saw, tapping block, pull bar, spacers, hammer, safety glasses, hearing protection, utility knife, wall spacers, straight edge, broom, speedy square, hardwood floor cleaner, and shop vacuum.


12 FL. Pad/ Underlayment

Eternity Premium Underlayment pad or comparable is recommended. Follow pad manufacturer's installation instructions. Always use a high quality, firm underlayment pad with a built-in moisture membrane.




13 FL. Lead with Groove

Cut off tongue on very first row to be installed and lead with the groove. This enables the tongue to be partially inserted into groove before coming into contact with the underlayment.



14 FL. Tongue and Groove Adhesive

Place a bead of white PVA / D3 rated tongue and groove glue into the bottom of the groove.




15 FL. Use Tapping Block

When tapping floor together with block start tapping from lead end and work back towards where the two end joints are coming together. Tapping back towards the floor tightens the end joint

16 FL. Tape/Strap Starter Rows

After three rows of flooring have been installed, take a 6' level and check the leading edge to be sure floor is on a straight line. Lay the level on its back and glide bottom edge along the tongue. Failure to stay on a straight line will cause irregular gaps in floor on sides and ends.




17 FL. Trim Last Row

Trim the last row to fit and pull into place with pull tool. Tape the last several rows in place to prevent accidental movement and opening of side joints.

18 FL. Install Lip/Over Transition

CAUTION: Do not attach lip/over moldings directly to the edge of the floor. Fasten transition lip/over moldings to the sub floor only. Attaching the lip/over to the edge of the floor prohibits the free movement of the floor.



Clean Up

- A. Clean up any adhesive or glue residue immediately. If glue or adhesive is allowed to dry on the floor's surface, it can damage the finish when it is removed.
- B. Adhesive residue, glue residue, and shoe marks can be removed with mineral spirits.
- C. Remove dust and dirt regularly during installation and upon completion with a soft brush attachment on a shop vacuum.
- D. Move refrigerators with a soft wheel dolly or glides to avoid denting floor. Do not install stiff copper tubing from water source to ice maker. Use flexible braid tubing instead. A braided hose is much more durable and less prone to leak.

